

Art. 5214113 - 5218184 - 7711166

Art. 5214739 - 7714313

MBK

BOOSTER 50 2T euro 0-1
BOOSTER 50 2T euro 2 (A137E)
BOOSTER SPIRIT 50 2T euro 0-1
BOOSTER NAKED 50 2T euro 2 (A137E)
BOOSTER NG 50 2T euro 0-1
BOOSTER NG 50 2T euro 2 (A137E)
BOOSTER ROCKET 50 2T euro 0-1
BOOSTER ROCKET 50 2T euro 2 (A137E)
STUNT 50 2T euro 0-1
STUNT 50 2T euro 2

YAMAHA

BW'S 50 2T euro 0-1
BW'S 50 2T euro 2 (A137E)
BW'S Original/Naked 50 2T euro 2 2010->
(A137E)
BW'S NG 50 2T euro 0-1
BW'S NG 50 2T euro 2 (A137E)
SLIDER 50 2T
ZUMA 50 2T

ATTENZIONE: per montare la CAMPANA Malossi é necessario TOGLIERE il materiale in eccesso all'interno del carter.

ATTENTION: in order to use Malossi CLUTCH BELL it is necessary to remove surplus material from the internal of the crankcase.

ATTENTION: pour monter la CLOCHE D'EMBRAYAGE Malossi, il faut enlever du matériel de l'intérieur du carter.

ACHTUNG: beim Montieren der Malossi KUPPLUNGSGLOCKE ist es erforderlich, das überschüssige Material am Motorgehäuse zu entfernen.

ATENCION: para montar la CAMPANA EMBRAGUE Malossi hay que sacar un poco de material desde el interior del cárter.